

**BOSE**

# LIFESTYLE<sup>®</sup> 600

## HOME ENTERTAINMENT SYSTEM



BRUGERVEJLEDNING • BEDIENUNGSANLEITUNG  
GEBUIKERSHANDLEIDING • KÄYTTÖOHJE  
MANUALE DI ISTRUZIONI • KEZELÉSI ÚTMUTATÓ  
BRUKERVEILEDNING • PODRĘCZNIK UŻYTKOWNIKA  
MANUAL DO PROPRIETÁRIO • BRUKSANVISNING

# IMPORTANT SAFETY INSTRUCTIONS

---

## Please read and keep all safety and use instructions.

### Important Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
10. Only use attachments/accessories specified by the manufacturer.
11. Unplug this apparatus during lightning storms or when unused for long periods of time.
12. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



This symbol on the product means there is uninsulated, dangerous voltage within the product enclosure that may present a risk of electrical shock.



This symbol means there are important operating and maintenance instructions in this guide.



Contains small parts which may be a choking hazard. Not suitable for children under age 3.



This product contains magnetic material. Consult your physician on whether this might affect your implantable medical device.



This product contains a tempered glass surface. Use caution to avoid impact. In the event of breakage, use care in handling broken glass.

- To reduce the risk of fire or electrical shock, do NOT expose this product to rain, liquids or moisture.
- Do NOT expose this product to dripping or splashing, and do not place objects filled with liquids, such as vases, on or near the product.
- Keep the product away from fire and heat sources. Do NOT place naked flame sources, such as lighted candles, on or near the product.
- Do NOT make unauthorized alterations to this product.
- Do NOT use a power inverter with this product.
- Do NOT use in vehicles or boats.
- The speaker wire and interconnect cables included with this system are not approved for in-wall installation. Please check your local building codes for the correct type of wire and cable required for in-wall installation.
- Use this product only with the power supply provided.
- Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- 仅适用于 2000m 以下地区安全使用  
Use at altitude less than 2000 meters only.
- Due to ventilation requirements, Bose does not recommend placing the product in a confined space such as in a wall cavity or in an enclosed cabinet.
- Do not place or install the bracket or product near any heat sources, such as fireplaces, radiators, heat registers or other apparatus (including amplifiers) that produce heat.
- The product label is located on the bottom of the console.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by Bose Corporation could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules and with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device for operation in the 5150 - 5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

W52/W53 for Indoor Use Only.

This device complies with FCC and Industry Canada radiation exposure limits set forth for general population.

This equipment should be installed and operated with a minimum distance of 20 cm between radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## Management Regulation for Low-power Radio-frequency Devices

### Article XII

According to "Management Regulation for Low-power Radio-frequency Devices" without permission granted by the NCC, any company, enterprise, or user is not allowed to change frequency, enhance transmitting power or alter original characteristic as well as performance to an approved low power radio-frequency devices.

### Article XIV

The low power radio-frequency devices shall not influence aircraft security and interfere legal communications; If found, the user shall cease operating immediately until no interference is achieved. The said legal communications means radio communications operated in compliance with the Telecommunications Act.

The low power radio-frequency devices must be susceptible with the interference from legal communications or ISM radio wave radiated devices.

 Bose Corporation hereby declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC and all other EU directive requirements. The complete declaration of conformity can be found at: [www.Bose.com/compliance](http://www.Bose.com/compliance)

 This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.

Names and Contents of Toxic or Hazardous Substances or Elements						
Toxic or Hazardous Substances and Elements						
Part Name	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent (CR(VI))	Polybrominated Biphenyl (PBB)	Polybrominated diphenylether (PBDE)
PCBs	X	0	0	0	0	0
Metal Parts	X	0	0	0	0	0
Plastic Parts	0	0	0	0	0	0
Speakers	X	0	0	0	0	0
Cables	X	0	0	0	0	0
This table is prepared in accordance with the provisions of SJ/T 11364. O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement of GB/T 26572. X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement of GB/T 26572.						

# REGULATORY INFORMATION

---

## Please complete and retain for your records

The serial and model numbers are located on the side of the carton.

Serial number: \_\_\_\_\_

Model number: \_\_\_\_\_

Please keep your receipt with your owner's guide. Now is a good time to register your Bose product.

You can easily do this by going to <http://global.Bose.com/register>

**Date of Manufacture:** The first bolded digit in the serial number indicates the year of manufacture; "6" is 2006 or 2016.

**China Importer:** Bose Electronics (Shanghai) Company Limited, Part C, Plan 9, No. 353 North Ruying Road, China (Shanghai) Pilot Free Trade Zone.

**EU Importer:** Bose GP, Castleblayney Road, Carrickmacross, County Monaghan, Ireland

**Mexico Importer:** Bose de México, S. de R.L. de C.V., Paseo de las Palmas 405-204, Lomas de Chapultepec, 11000 México, D.F. Phone number: 001 800 900 2673.

**Taiwan Importer:** Bose Taiwan Branch, 9F-A1, No.10, Section 3, Minsheng East Road, Taipei City 104, Taiwan. Phone number: 886 2 2514 7977.

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android, Google Play, and the Google Play logo are trademarks of Google Inc.

©2013 CSR plc and its group of companies. The aptX® mark and the aptX logo are trademarks of CSR plc or one of its group companies and may be registered in one or more jurisdictions.

The *Bluetooth*® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Bose Corporation is under license.

**DOLBY AUDIO**™ Dolby, Dolby Audio and the double-D symbol are trademarks of Dolby Laboratories.



For DTS patents, see <http://patents.DTS.com>. Manufactured under license from Digital Theater Systems, Inc. DTS, the Symbol & DTS and the Symbol together are registered trademarks, and DTS Digital Surround is a trademark of DTS, Inc. ©DTS, Inc. All Rights Reserved.



The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

iHeartRadio is a registered trademark of iHeartMedia, Inc.

Deezer is a registered trademark of Blogmusik SAS.

This product is protected by certain intellectual property rights of Microsoft. Use or distribution of such technology outside of this product is prohibited without a license from Microsoft.

The N-Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries.

Pandora, the Pandora logo, and the Pandora trade dress are trademarks or registered trademarks of Pandora Media, Inc. used with permission.

SiriusXM Internet Radio subscription sold separately and available only to those at least 18 years of age residing in the U.S. and Puerto Rico. To subscribe to SiriusXM Internet Radio in the U.S., U.S. customers should visit [www.sirius.com](http://www.sirius.com) or call 1-888-539-7474.

SiriusXM and all related marks and logos are trademarks of Sirius XM Radio Inc. and its subsidiaries. All rights reserved.

SoundTouch and the wireless note design are registered trademarks of Bose Corporation in the U.S. and other countries.

This product incorporates Spotify software which is subject to 3rd party licenses found here: [www.spotify.com/connect/third-party-licenses](http://www.spotify.com/connect/third-party-licenses)

Spotify is a registered trademark of Spotify AB.

Designed with UEI Technology™. Under License from Universal Electronics, Inc. © UEI 2000-2016

Wi-Fi is a registered trademark of Wi-Fi Alliance®.

Windows is a registered trademark of Microsoft Corporation in the United States and other countries.

©2016 Bose Corporation. No part of this work may be reproduced, modified, distributed or otherwise used without prior written permission.

**Getting Started**

Unpacking ..... 8

    Layer 1 ..... 9

    Layer 2 ..... 9

    Layer 3 ..... 10

    Layer 4 ..... 10

Placement guidelines ..... 11

Sample system placement ..... 12

**Setting Up the System**

UNIFY® system overview ..... 13

UNIFY® setup ..... 14

**Using the Remote Control**

Remote control overview ..... 15

Using the SOURCE button ..... 16

Function buttons ..... 16

Adjusting volume ..... 16

Power saver mode ..... 16

Using the MORE button ..... 16

The OPTIONS menu ..... 17

**Setting Up SoundTouch®**

Setting up SoundTouch® on your system ..... 18

Download and install the SoundTouch® app ..... 18

    Connect the system to your Wi-Fi® network ..... 18

Adding the system to an existing SoundTouch® account ..... 19

Connecting the system to a new network ..... 19

**Using the SoundTouch® App**

Getting help ..... 20

In-app help ..... 20

Controlling the system from another smartphone or tablet ..... 20

**Personalizing Your Presets**

How Presets work ..... 21

Setting a Preset ..... 21

Playing a Preset ..... 21

Setting a Preset using your remote control ..... 21

Selecting a Preset using your remote control ..... 21

# CONTENTS

---

## **Bluetooth® Technology**

Pairing a device .....	22
Pairing a device with NFC .....	23
Controlling your connected mobile device from the remote control .....	23
Connecting to a paired device .....	24
Disconnecting a device .....	24
Reconnecting a device .....	24
Clearing the console's pairing list .....	24
Using the SoundTouch® app .....	24

## **Advanced Features**

Disabling Wi-Fi® capability .....	25
Re-enabling Wi-Fi® capability .....	25
Updating the system software .....	25

## **Getting System Information**

System status indicators .....	26
Console LED indicator .....	26
Acoustimass® wireless bass module LED indicator .....	27
Wireless receiver LED indicator .....	27

## **Care and Maintenance**

Cleaning .....	28
Customer service .....	28
Limited warranty .....	28
Technical information .....	28
SERVICE connector .....	28

## **Troubleshooting**

Common solutions .....	29
Setting up your IR emitter .....	32
Unable to pair the Acoustimass® wireless bass module with the console .....	33
Checking for sound .....	33

**Appendix A: installation reference**

Front console panel..... 34

    Front Headphones/AUX input..... 34

    Front HDMI™ input..... 34

Back console panel..... 34

Connecting an AC-2 adapter ..... 35

Installing the front speakers..... 36

Connecting the front speakers to the console ..... 37

Installing the rear speakers ..... 38

Identifying switch settings on wireless receivers..... 39

Connecting the rear speakers..... 39

Connecting the rear speakers to power ..... 40

Making a wired connection to the rear speakers ..... 40

Mounting your speakers ..... 40


**Appendix B: System Maintenance**

Replacing the remote control's batteries ..... 41

## Unpacking

---

The parts of your new Lifestyle® Home Entertainment System are packaged in four layers, some of which contain multiple boxes of components. Each box is marked by icons to indicate its contents.




### Notes:

- When prompted by UNIFY® setup, carefully unpack your system according to the icons referenced in the on-screen steps.
- If part of the system is damaged or the glass on your console or Acoustimass® wireless bass module is broken, do not use it. Contact your authorized Bose® dealer or Bose customer service.


Refer to the contact sheet in box  .

## Layer 1


From box    :




Console (1)



HDMI™ cable (1)




Universal remote control (1)



AA batteries (4)

## Layer 2

From box  :



Console power supply (1)

From box   :



Power cords (4)



Owner's guide (1)


 May ship with multiple power cords. Use the power cord for your region.

# GETTING STARTED


---

## Layer 3

From box    :



Jewel Cube® speakers (4)



Jewel Cube® center speaker (1)



Front speaker cable (1)



Rear speaker cables (2)




AC-2 adapters (5)

From box  :




Wireless receivers (2)

From box   :



ADAPTIQ® headset (1)




Screwdriver (1)



IR emitter (1)

## Layer 4

From box  :



Acoustimass® wireless bass module (1)


## Placement guidelines

To avoid interference, keep other wireless equipment 1 – 3 ft. (0.3 – 0.9 m) away from the system. Place your system outside of and away from metal objects and away from other audio/video components and direct heat sources.

Component	Recommended placement
Console	<ul style="list-style-type: none"> <li>• Place the console near your components. The recommended placement is near your TV.</li> <li>• Do NOT place the TV or any other components on top of your console.</li> <li>• Place your console in a well-ventilated area.</li> <li>• Make sure there is an AC (mains) outlet nearby.</li> </ul> <p><b>Note:</b> Until your system is completely installed, keep the control console positioned for easy access to its rear connector panel.</p>
Acoustimass® wireless bass module	<ul style="list-style-type: none"> <li>• Stand the bass module on its rubber feet along the same wall as your TV, or along any other wall in the front third of the room.</li> <li>• Choose a stable and level surface. Vibration can cause the bass module to move, particularly on smooth surfaces like marble, glass or highly polished wood.</li> <li>• Keep the front side of the bass module at least 3 in. (8 cm) from any other surface. Blocking the port on the bottom of this side can affect acoustic performance.</li> <li>• Make sure there is an AC (mains) outlet nearby.</li> </ul>
Front speakers	<ul style="list-style-type: none"> <li>• Place one speaker to the left and one speaker to the right of the TV.</li> <li>• If placing the speakers in an enclosed bookcase shelf, position them at the front edge of the shelf.</li> </ul>
Center speaker	<ul style="list-style-type: none"> <li>• Place the center speaker on a stable and level surface directly above or below your TV.</li> </ul>
Rear speakers/ wireless receivers	<ul style="list-style-type: none"> <li>• Place the rear speakers toward the back of the room behind the viewers at ear height (when seated) or higher, if possible.</li> <li>• Confirm that the switch on one wireless receiver is set to <b>L</b> (left).</li> <li>• Confirm that the switch on the other wireless receiver is set to <b>R</b> (right).</li> <li>• Facing the TV, place the speaker and <b>L</b> wireless receiver on the left side of the room.</li> <li>• Facing the TV, place the speaker and <b>R</b> wireless receiver on the right side of the room.</li> <li>• Make sure there is an AC (mains) outlet near each wireless receiver.</li> </ul>

## Sample system placement

---



## UNIFY® system overview

The UNIFY intelligent integration system guides you through the initial process of setting up and configuring your system. It helps you choose the correct cables and inputs and programs the Bose® remote control to operate your connected devices.

**Note:** Before you begin, make sure you have one hour set aside for system setup.

Menu item	What you can do
Language	Change the language of the on-screen display.
ADAPTiQ®	Start the ADAPTiQ audio calibration process. Once completed, this menu option disables or enables ADAPTiQ.
TV setup	After your TV is connected to the console: <ul style="list-style-type: none"> <li>• Program the remote control to use your TV.</li> <li>• Connect a new TV to the console.</li> <li>• Add, change or remove the TV audio connection.</li> </ul>
Source setup	For sources connected to HDMI™ inputs 1 – 5 of the control console: <ul style="list-style-type: none"> <li>• Rename the device.</li> <li>• Program the remote control to access the device.</li> <li>• Remove the device.</li> <li>• Add or change the type of audio/video connection.</li> </ul>
Add a new device	Add another device or accessory to your system.
Network setup	Connect your system to your home network.
Update	Perform a system software update.
Exit UNIFY	Close the UNIFY menu.

### UNIFY® setup

---

The following steps are part of the initial UNIFY setup process:

Step	Objective
Pair the remote control	Connect the system's remote control to the console.
Choose language	Select your language from the on-screen list.
Connect to network	Select and connect to your home Wi-Fi network.
Software update	Update system software to provide the most current functionality.
Wired speakers	Connect the front speakers to the console.
Wireless speakers	Connect the rear speakers and Acoustimass® wireless bass module to the console.
TV remote	Set up the system's remote control to control your TV.
Adding devices	Connect your additional sources.
ADAPTiQ® setup	Customizes the sound of the system to the acoustics of your listening area.
Tutorial	A series of optional procedures to help guide you through the rest of your system's features, such as SoundTouch® and Bluetooth® operation.


After completing the initial setup, you can access UNIFY menu at any time to change your system setup and configuration. Press the **SETUP** button on the front of your console or the remote control to start UNIFY setup.

## Remote control overview

The Bose® advanced RF (radio frequency) remote control works from anywhere in your room without requiring you to aim the remote control at the console.

The remote control's display is an essential part of your Lifestyle® experience. It guides you through your sources and system settings.

**Note:** The Bose remote control does not control functions specific to devices that are connected to the front HDMI™ input.



### Using the SOURCE button

---

The **SOURCE** button is used to switch between connected sources. Access sources using the navigation pad on your remote control.

### Function buttons

---

The red, green, yellow and blue buttons on the remote control correspond with the color-coded function buttons on your cable/satellite box or teletext functions.

- **Cable/satellite box functions:** refer to your cable/satellite box owner's guide.
- **Teletext functions:** correspond with color-coded page numbers, headings or shortcuts on a teletext display.

### Adjusting volume

---

To see your volume level, refer to your remote control's display.

- Press **+** to increase the volume.
- Press **-** to decrease the volume.
- Press **⏏** to mute or unmute the audio.

**Note:** If you still hear audio from your TV's speakers after setting up your system, disable the speakers through your TV's settings menu.

### Power saver mode

---

Power saver mode conserves battery life by dimming the brightness of your remote control's display and adjusting the duration that the display remains actively lit.

To access power saver mode, press the **SETUP** button on your remote control.

### Using the MORE button

---

The **MORE** button  on your remote displays additional selections on your remote control's display that are applicable to your currently selected source.

1. Press .
2. Press  or  to select a function on your remote control's display.
3. Press OK.

## The **OPTIONS** menu

---

The **OPTIONS** menu displays a list of functions that let you adjust certain system settings. The number of items that appear in the **OPTIONS** menu depends on which source is currently selected. Regardless of the source, you have access to the **OPTIONS** menu.

**Note:** The **OPTIONS** menu is only accessible through your system's remote control after pressing the **MORE** button .

To activate the **OPTIONS** menu:

1. Press  on your remote control.
2. Highlight the **OPTIONS** button.
3. Press the **OK** button to display the **OPTIONS** menu for the current source.
4. Press  or  to highlight the option you want to change.
5. Press **OK** to select the setting.
6. Press **EXIT** when done.

## SETTING UP SOUNDTOUCH®

---

The SoundTouch® app lets you set up and control SoundTouch® from your smartphone or tablet. Using the app, your smart device acts as a remote for your system.

From the app, you can manage your SoundTouch® settings, add music services, explore local and global Internet radio stations, set and change Presets, and stream music. New features are added periodically.

### Setting up SoundTouch® on your system

---

After you connect the system to power, download and install the SoundTouch® app onto a smartphone or tablet that is connected to your network.

The app guides you through setting up SoundTouch® on your system.

**Note:** If you have already set up SoundTouch® for another system, see “Adding the system to an existing SoundTouch® account” on page 19.

### Download and install the SoundTouch® app

---

On your smartphone or tablet, download the Bose® SoundTouch® controller app.



**Bose® SoundTouch®  
controller app**

- **Apple users:** download from the App Store
- **Android™ users:** download on the Google Play™ store
- **Amazon Kindle Fire users:** download from the Amazon Appstore for Android

### Connect the system to your Wi-Fi® network

After you download and install the app, connect your system to your network:

1. On your smartphone or tablet, select the SoundTouch® icon  to open the app.
2. Follow the instructions in the app to complete setup, including creating a SoundTouch® account, adding a music library and music services.

## Adding the system to an existing SoundTouch® account

---

If you have already set up SoundTouch® on another system, you do not need to download the SoundTouch® app again.

1. On your smartphone or tablet, select the SoundTouch® icon  to open the app.
2. Select **EXPLORE > SETTINGS > Add or reconnect system**.

The app guides you through setup.

## Connecting the system to a new network

---

If your network information changes, add your system to your new network. You can do this by putting the system into setup mode.

1. On your smartphone or tablet, select the SoundTouch® icon  to open the app.
2. Select **EXPLORE > SETTINGS > System settings** and select your system.
3. Select **CONNECT SYSTEM**.

The app guides you through setup.

## USING THE SOUNDTOUCH® APP

---

After you set up the SoundTouch® app, you are ready to stream music and personalize your Presets.

### Getting help

---

 [global.bose.com/Support/LS600](https://global.bose.com/Support/LS600)

This website provides access to the owner support center, which includes: owner's manuals, articles, tips, tutorials, a video library and the owner community where you can post questions and answers.

### In-app help

---

The In-app help provides information on using SoundTouch®.

1. On your mobile device, select the SoundTouch® icon  to open the app.
2. Select **EXPLORE > HELP**.

### Controlling the system from another smartphone or tablet

---

Once you set up the SoundTouch® system on your home Wi-Fi® network, you can control the system from any smartphone or tablet on the same network.

1. Connect the device to the same network as your system.
2. On the device, download and install the SoundTouch® app (see page 18).

## How Presets work

---

You can personalize six Presets to your favorite streaming music services, stations, playlists, artists, albums or songs from your music library. You can access your music, at any time, with a simple touch of a button using the SoundTouch® app on your smartphone or tablet.

### What you need to know

- You can set Presets from the app and your remote control.
- You cannot set Presets to a *Bluetooth*® stream.

## Setting a Preset

---

1. Stream music to the system using the app.
2. While the music is playing, press and hold a Preset in the app.

**Note:** For information on using the SoundTouch® app to set and change your Presets, refer to the in-app help.

## Playing a Preset

---

Once you personalize your Presets, press a Preset in the app to play it.

## Setting a Preset using your remote control

---

1. Press the  on your remote control to access the SoundTouch source.
2. Press and hold a number (from 1 – 6) on the numeric keypad to assign a new Preset. A tone notifies you that a new Preset has been set.

## Selecting a Preset using your remote control

---

1. Assign your favorite stations as Presets within the app.
2. Press the **SoundTouch**® button  on your remote control to switch to the SoundTouch source.
3. Select a Preset by pressing a number (from 1 – 6) on the numeric keypad. The buttons are highlighted blue on your remote control for reference.

## BLUETOOTH® TECHNOLOGY

---

*Bluetooth*® wireless technology lets you stream music from mobile devices, such as smartphones, tablets and laptops. Before you can stream music from a mobile device, you must pair the mobile device with the console.

### Choosing your pairing method

You can pair your mobile device with the console using *Bluetooth* wireless technology or Near Field Communication (NFC).

#### What is NFC?

NFC is a technology that enables devices to establish wireless communication with each other by simply tapping the devices together. Refer to your device owner's guide to see if your model supports NFC.

<b>If your device does not support NFC or if you are unsure:</b>	Follow the instructions for "Pairing a device."
<b>If your device supports NFC:</b>	Follow the instructions for "Pairing a device with NFC" on page 23.

**Note:** If your device supports *Bluetooth* pairing via NFC, you can use either pairing method.

### Pairing a device

---

1. Press the **SOURCE** button on your remote control and select **Bluetooth**® from the on-screen menu.
2. Follow the on-screen instructions to place your console in pairing mode.
3. On your device, turn on the *Bluetooth* feature.

**Tip:** The *Bluetooth* feature is usually found in the Settings menu.



4. Select your system from the device list.  
Once connected, your system's name appears connected in the device list.


---

## Pairing a device with NFC

---

1. With your system powered on, unlock your device and turn on the *Bluetooth*® and NFC features. Refer to your device owner's guide to learn more about these features.
2. Gently tap the NFC touchpoint on your mobile device to the area above the Bose® logo on the top of your Lifestyle® console.

Your mobile device may prompt you to accept pairing.



---

## Controlling your connected mobile device from the remote control

---

Once paired, you can use the remote control to access your connected mobile devices. Select *Bluetooth* from the **SOURCE** menu. To pair a device, see page 22.

You can use the remote to control the following subset of *Bluetooth* features on your system:

- Pair and connect devices.
- View available artist information in the NOW PLAYING panel.
- Control playback (play, pause, stop, skip to the next track, etc.).
- Clear the pairing list.

## Connecting to a paired device

---

You can stream audio from a device to your console.

1. Turn on the *Bluetooth*® feature on your device.
2. On your remote control, choose the *Bluetooth* source through the **SOURCE** menu.  
The console connects to the last device that streamed music to the system.
3. On the device, play music.

### If you can't stream audio from a paired device

The system may have lost the connection to the device. If the paired device is out of range of the system, move the device within range.

## Disconnecting a device

---

- Turn off the *Bluetooth* feature on your device.
- If your device supports NFC, tap the NFC touchpoint on your device to the top of the console above the Bose® logo.

## Reconnecting a device

---

- When powered on, the console tries to reconnect with the most recently connected device.  
**Note:** The device must be within range and powered on.
- If your device supports NFC, gently tap the NFC touchpoint on your mobile device to the area above the Bose® logo on the top of your console.

## Clearing the console's pairing list

---

You can store up to eight paired devices in the console's pairing list.

1. On your remote control, choose the *Bluetooth* source through the **SOURCE** menu.
2. In the *Bluetooth* source, press the **MORE** button  on your remote.
3. Select **CLEAR LIST**.  
All devices are cleared.

### Using the SoundTouch® app

You can also clear the pairing list using the app.

1. On your mobile device, select the SoundTouch® icon  to open the app.
2. Select **EXPLORE > SETTINGS > System settings** and select your system.
3. Open the *Bluetooth*® menu item and clear the pairing list.

## Disabling Wi-Fi® capability

---

Disabling Wi-Fi® also disables the *Bluetooth*® feature.

1. Press and hold your console's **SOURCE** button until the system status indicator blinks.
2. Release the **SOURCE** button.

## Re-enabling Wi-Fi® capability

---

Re-enabling Wi-Fi® also re-enables the *Bluetooth*® feature.

Your system's Wi-Fi® automatically re-enables upon restarting the system.

## Updating the system software

---


If your system is connected to your home network, it checks for software updates every time the system is used. If an update is available, it begins downloading automatically.

If an update was fully downloaded, on-screen text prompts you when powering down the console that it is ready to be installed. Your system shuts down automatically after installation.

## System status indicators


The front of the console has an LED indicator that shows system status. The LED glows according to system state.

### Console LED indicator




Indicator activity	System state
Off	System is off
Blinking white	System is powering on
Solid white	System powered on
Blinking amber	Downloading system software update
Blinking amber (five seconds on, one second off)	In standby
Blinking red (five seconds on, one second off)	Remote control battery low
Solid red	Firmware error - contact Bose® customer service

## Acoustimass® wireless bass module LED indicator



Indicator activity	System state
Blinking amber	Ready to pair
Solid white	Connected to the console
Solid amber (dim)	Disconnected from the console
Blinking white	Downloading system software update
Blinking red	Firmware error - contact Bose® customer service

## Wireless receiver LED indicator



Indicator activity	System state
Blinking amber	Ready to pair
Solid white	Connected to the console
Solid amber (dim)	Disconnected from the console
Blinking white	Downloading system software update
Blinking red	Firmware error - contact Bose® customer service

### Cleaning

---



Do not allow liquids to spill onto the system or into any openings.

- Clean the exterior of the system with the provided cleaning cloth or another soft, dry cloth.
- Do not use any sprays near the system.
- Do not use any solvents, chemicals or cleaning solutions containing alcohol, ammonia or abrasives.
- Do not allow objects to drop into any openings.

### Customer service

---

For additional help using the system:

- Visit [global.bose.com/Support/LS600](http://global.bose.com/Support/LS600)
- Contact Bose® customer service. Refer to the contact sheet in box   for additional information.

### Limited warranty

---

Your system is covered by a limited warranty. Details of the limited warranty are provided on the product registration card that is in the carton. Please refer to the card for instructions on how to register. Failure to do so will not affect your limited warranty rights.

The warranty information provided with this product does not apply in Australia and New Zealand. See our website at [www.bose.com.au/warranty](http://www.bose.com.au/warranty) or [www.bose.co.nz/warranty](http://www.bose.co.nz/warranty) for details of the Australia and New Zealand warranty.

### Technical information

---


#### U.S.A./Canada/International:

- **Console:** 10VDC 3.3A, 44VDC 1.25A
- **Wireless receivers:** 100–240V 50/60 Hz, 30W
- **Acoustimass® wireless bass module:** 100–240V  $\sim$  50/60 Hz, 180W

### SERVICE connector

---

The SERVICE connector is for service use only. Do not insert any cables into this connector.



If you experience problems with your home entertainment system:

- Make sure that all system components are connected to an AC (mains) outlet.
- Secure all cables.
- Check the state of system status indicators (see page 26).
- Move the system away from possible interference (wireless routers, cordless phones, televisions, microwaves, etc.).
- Verify the system is within the recommended range of wireless router or mobile device for proper operation.

If you continue to experience problems, see “Common solutions” before contacting Bose® customer service. This table is designed to help you identify and correct problems that may occur with your Bose product.

## Common solutions

The following table lists symptoms and possible solutions to common problems.

Symptom	Solution
The system is not responding to initial operation of remote control	<ul style="list-style-type: none"> <li>• Power on the control console manually from the front of the unit by pressing the <b>Power</b> button .</li> <li>• Press any button on your remote control. The system status indicator on the control console should blink with each press.</li> <li>• Make sure the remote control's batteries are installed correctly and do not need replacement (see page 41).</li> <li>• Unplug the power cord for the console, wait 30 seconds and plug it firmly into a live AC (mains) outlet.</li> </ul>
The remote does not control a device added during initial setup	Connect your IR emitter (see page 32).
The TV is still playing sound	Disable your TV speakers through your TV's settings menu.
Poor video connection from a source	Press the <b>SETUP</b> button on the control console and select your device's setup options. Follow the on-screen instructions to change a video connection.
System does not respond	<ul style="list-style-type: none"> <li>• Select a connected device from the <b>SOURCE</b> menu.</li> <li>• Press and hold  on the front of the console to cycle your system's power.</li> <li>• Unplug the power cord for the console, wait 30 seconds and plug it firmly into a live AC (mains) outlet.</li> </ul>

## TROUBLESHOOTING

---

Symptom	Solution
No sound from the system	<ul style="list-style-type: none"> <li>• Increase the volume.</li> <li>• Press the <b>Mute</b> button  on the remote control to make sure the system is not muted.</li> <li>• Make sure you have selected the correct source.</li> <li>• Cycle through and test different sources.</li> <li>• Make sure that the HDMI™ cable is inserted into a connector on your TV labeled <b>ARC</b> or <b>Audio Return Channel</b>. If your TV does not have an HDMI ARC connector, use a secondary audio cable in addition to the HDMI cable.</li> <li>• If using a secondary audio cable, insert the cable into a connector on your TV labeled <b>Output</b> or <b>OUT</b>.</li> <li>• Press and hold the <b>Power</b> button  on the front of the console to cycle your system's power.</li> <li>• Unplug the power cord for the console, wait 30 seconds and plug it firmly into a live AC (mains) outlet.</li> </ul>
Cannot complete network setup	<ul style="list-style-type: none"> <li>• Select the correct network name and enter password (case sensitive).</li> <li>• Connect to the network using an Ethernet cable.</li> <li>• Restart your modem and router.</li> </ul>
Cannot complete SoundTouch® setup	<ul style="list-style-type: none"> <li>• Connect the mobile device and the system to the same Wi-Fi® network.</li> <li>• Enable Wi-Fi on the mobile device you are using for setup.</li> <li>• Test your internet connection.</li> <li>• Restart your mobile device.</li> <li>• Restart your modem and router.</li> <li>• Uninstall the app, reinstall the app, reset the system and restart setup.</li> </ul>
Acoustimass® wireless bass module status LED is a solid amber (dim)	<ul style="list-style-type: none"> <li>• Follow the on-screen troubleshooting prompts.</li> <li>• Press the <b>SETUP</b> button on the control console or your remote and rerun the UNIFY® setup (see page 14).</li> <li>• Connect the bass module using a 3.5 mm stereo cable (see page 33). If you don't have a 3.5 mm stereo cable, contact Bose® customer service. Refer to the contact sheet in the carton.</li> <li>• Unplug the power cord for the Acoustimass, wait 30 seconds and plug it firmly into a live AC (mains) outlet.</li> </ul>
Bass is too heavy or low	<ul style="list-style-type: none"> <li>• Adjust the bass setting of the system (see page 17).</li> <li>• Run ADAPTiQ® audio calibration (see page 14).</li> <li>• Move the bass module away from nearby walls and corners.</li> </ul>

Symptom	Solution
The wireless receiver status LEDs are solid amber (dim)	<ul style="list-style-type: none"> <li>• Follow the on-screen troubleshooting prompts.</li> <li>• Press the <b>SETUP</b> button on the control console or your remote and rerun the UNIFY® setup (see page 14).</li> <li>• Unplug the power cords for the receivers, wait 30 seconds and plug them firmly into a live AC (mains) outlet.</li> <li>• Make a wired connection to your rear speakers. Contact Bose® customer service. Refer to the contact sheet in the carton.</li> </ul>
Sound is distorted	<ul style="list-style-type: none"> <li>• Cycle through and test different sources.</li> <li>• Reduce the volume output level from any devices connected to the control console.</li> <li>• Make sure the audio input cable from your source device is connected and not damaged.</li> <li>• If you have not previously run ADAPTiQ®, select <b>ADAPTiQ®</b> from the UNIFY® menu (see page 13).</li> <li>• Unplug the power cord for the console, wait 30 seconds and plug it firmly into a live AC (mains) outlet.</li> </ul>
No sound from a connected device	<ul style="list-style-type: none"> <li>• Power on the device.</li> <li>• Cycle through and test different sources.</li> <li>• Refer to the device owner's manual.</li> </ul>
No TV picture, but audio is heard	Make sure the TV video input selection is correct for the video source.
A connected device is not responding consistently to remote commands	<ul style="list-style-type: none"> <li>• Try setting up the device again. Press the <b>SETUP</b> button on the control console. Select the device options and follow the on-screen instructions to set up the device again.</li> <li>• Replace your remote's batteries (see page 41).</li> <li>• Set up your IR emitter (see page 32).</li> </ul>
Intermittent audio dropouts heard on coaxial digital audio devices	<ul style="list-style-type: none"> <li>• Confirm that the audio cable is properly connected to the console and the coaxial digital audio device.</li> <li>• Cycle through and test different sources.</li> <li>• Try setting up the device again. Press the <b>SETUP</b> button on the control console. Select the coaxial digital audio device options and follow the on-screen instructions to set up the device again.</li> <li>• Unplug the power cord for the console, wait 30 seconds and plug it firmly into a live AC (mains) outlet.</li> </ul>
Connecting to a new network or different network	<ul style="list-style-type: none"> <li>• If your network information has changed or to connect your system to another network, refer to the SoundTouch® in-app help.</li> <li>• If having problems connecting wirelessly, connect to the network using an Ethernet cable.</li> </ul>

## TROUBLESHOOTING

---

Symptom	Solution
Cannot play <i>Bluetooth</i> ® audio	<p>On your system:</p> <ul style="list-style-type: none"><li>• Pair a mobile device using the <i>Bluetooth</i> SOURCE screen.</li><li>• Clear the system's pairing list using the SoundTouch® app:<ul style="list-style-type: none"><li>- In the <i>Bluetooth</i> source, press the <b>MORE</b> button  on your remote.</li><li>- Select <b>CLEAR LIST</b>.</li></ul></li><li>• Try pairing a different mobile device.</li></ul> <p>On your mobile device:</p> <ul style="list-style-type: none"><li>• Disable and re-enable the <i>Bluetooth</i> feature.</li><li>• Remove the system from the <i>Bluetooth</i> menu. Pair again.</li><li>• Refer to your device's documentation.</li><li>• See "No sound from the system" on page 30.</li></ul>


## Setting up your IR emitter

---


If you are having issues with the responsiveness of your remote and your connected devices, Bose® recommends using the provided IR emitter.

**Note:** Use the IR emitters only if you are having remote control issues from a third party device.

1. Remove the IR emitter from box  .
2. Insert the emitter into the **IR** connector on the back of the console.



3. Remove three adhesive pads from the plastic sheet included with the emitter and place them on the flat bottoms of the three emitter beads.



4. Remove the plastic backing from the adhesive pads.

5. Place the three IR beads into the cabinet housing your device or directly in front of the device itself.
6. Test the responsiveness of your remote. If problems still exist, reposition the IR beads and test again.

## Unable to pair the Acoustimass® wireless bass module with the console


If you are unable to pair the bass module with the console, you can also connect the module to the soundbar using a 3.5 mm stereo cable (not provided).

Use this method only if you are having issues wirelessly connecting your bass module to your console.

**Note:** If you don't have a 3.5 mm stereo cable (commonly used for headphones and mobile devices), contact Bose® customer service to receive this part.

Refer to the contact sheet in box  .

1. Connect one end of a 3.5 mm stereo cable to the **ACOUSTIMASS IN** connector on the back of the bass module.
2. Connect the other end of the cable to the **ACOUSTIMASS** connector on the back of your console.



3. Turn on your system and check for sound.

## Checking for sound

1. Power on your TV.
2. If you are using a cable/satellite box or other secondary source:
  - Power on this source.
  - If your secondary source is connected to your TV, select the appropriate TV input.
3. Power on your console.

You should hear sound coming from the bass module.

**Note:** If you do not hear sound from the bass module, see “Troubleshooting” on page 30.


## Front console panel

---

The front of the console has the following inputs:

- Headphones
- HDMI™ input

These inputs appear in the **SOURCE** menu as AUX (Front) and HDMI (Front) when a device is connected. They can be used to connect digital cameras, video cameras, media players and your preferred mobile device.



### Front Headphones/AUX input

You can use this 3.5 mm input with your headphones, or as a quick plug-and-play audio option with your favorite mobile device. The headphone is the default option.

If you'd like to use this input as an AUX IN, press the **SOURCE** button on your remote control and select **Settings** in the on-screen display.


### Front HDMI™ input

You can use this input for devices that have an HDMI output.

**Note:** The Bose remote control does not control functions specific to devices that are connected to the front HDMI™ input.

## Back console panel


---




## Connecting an AC-2 adapter

Your system comes with AC-2 adapters used to connect the front and rear speaker wires to your speakers. Use this step when it is referenced to set up your system.

1. Using the screwdriver, turn the screws to the left (counterclockwise) to loosen the wire terminals.



2. Insert the red, stripped end of the two-pin cable marked + into the red + terminal.
3. Insert the black, stripped end of the two-pin cable into the silver - terminal.



**Note:** Be sure to only insert the bare ends of each exposed wire to avoid clamping the wire's insulation.

4. Using the screwdriver, turn the screws right (clockwise) to secure the wires into the terminals.
5. Repeat steps 1 - 4 to connect the other adapter.

## Installing the front speakers

---


UNIFY® guides you through the initial installation of your front speakers during the “Wired speakers” step (see page 14).

If you are moving your system but have already completed setup, refer to the following instructions in order to reassemble the rear portion of your home entertainment system.


**CAUTION:** Do not connect your speakers while your console is connected to an AC (mains) adapter.

### What you need:

From box  :



Jewel Cube® speakers (2)



Jewel Cube® center speaker (1)




AC-2 adapters (3)



Front speaker cable (1)


From box  :



Screwdriver (1)

## Connecting the front speakers to the console

1. Connect the AC-2 adapters to the bare ends of the speaker wire. See “Connecting an AC-2 adapter” on page 35.
2. Insert the adapter connected to the wire marked **L+** into the speaker on the left of your TV.
3. Insert the adapter connected to the wire marked **R+** into the speaker on the right of your TV.
4. Insert the adapter connected to the wire marked **C+** into the center speaker.
5. Connect the remaining end of the six-pin cable into the six-pin **FRONT SPEAKERS** connector on the back of your console.



**Note:** The four-pin FRONT SPEAKERS connector on the back of your console is not used.

## Installing the rear speakers


---

UNIFY® guides you through the initial installation of your rear speakers during the “Wireless speakers” step (see page 14).

If you are moving your system but have already completed setup, refer to the following instructions in order to reassemble the rear portion of your home entertainment system.

### What you need:

From box   :



Jewel Cube® speakers (2)



Rear speaker cables (2)



AC-2 adapters (2)

From box  :




Wireless receivers (2)

From box   :



Power cords (2)

From box   :




Screwdriver (1)

## Identifying switch settings on wireless receivers

Your rear speakers connect to wireless receivers to communicate with the console. The receivers come preset to a left and right channel out of the box. You can use the switch on the front of the receiver to adjust the channel settings.

1. Confirm that the switch on one wireless receiver is set to **L** (left).
2. Confirm that the switch on the other wireless receiver is set to **R** (right).




**Note:** Make sure that one wireless receiver is always set to **L** (left) and the other is set to **R** (right).

## Connecting the rear speakers

1. Connect the AC-2 adapters to the bare ends of the speaker wire. See “Connecting an AC-2 adapter” on page 35.
2. Insert the adapter into the back of your speaker.
3. Insert the other end of the two-pin cable into your wireless receiver.

You hear or feel a click.




4. Repeat steps 1 – 3 to connect your other speaker.

## Connecting the rear speakers to power

---

1. Connect one end of the power cord into your wireless receiver.
2. Plug the other end of the power cord into an AC (mains) outlet.



3. Repeat steps 1 and 2 to set up your other speaker.

## Making a wired connection to the rear speakers

---

You can also hard wire your rear speakers through the use of an adapter kit (sold separately).

To purchase the kit, contact your local Bose® dealer or visit [www.Bose.com](http://www.Bose.com)

**CAUTION:** Do not use any unauthorized wiring to connect the speakers to your Bose system. Using unauthorized wires may damage your Bose system and its components.

## Mounting your speakers

---

You can mount the speakers on wall brackets, floor stands or table stands. To purchase these accessories, contact your local Bose® dealer or visit [www.Bose.com](http://www.Bose.com)


### CAUTIONS:

- Only use Bose hardware to mount the speakers. Using unauthorized mounts may damage your Bose system and its components.
- The speaker wire and interconnect cables included with this system are not approved for in-wall installation. Please check your local building codes for the correct type of wire and cable required for in-wall installation.


## Replacing the remote control's batteries

Replace all four batteries when there is a noticeable decrease in range or when you see the console LED indicator blink red (see page 26).

1. Slide open the battery compartment cover on the back of the remote control.
2. Install four AA (IEC LR6) 1.5V batteries. Match the + and - symbols on the batteries with the + and - markings inside the compartment.



3. Slide the battery compartment cover back into place.



781533-0010

***BOSE***<sup>®</sup>  
*Better sound through research*<sup>®</sup>

©2016 Bose Corporation, The Mountain,  
Framingham, MA 01701-9168 USA  
AM781533 Rev. 00