


SecureCom GPRS alarm monitoring communicator



Installation

USB power is not sufficient for the operation, however, the voltage outputs (AUX) of alarm control panels are generally compliant.

- The TIP/RING communication line of the alarm control panel needs to be connected to the TIP/RING input of the communicator.
- Place the SIM card into the SIM card slot of the device.
- Connect the antenna.
- Power up the device.

Connect the USB cable, run the software and configure the communicator.

Functional description

The communicator is a device for using in alarm systems for the purpose of reporting via the GPRS networks, comply with the standard ANSI/SIA DC-09.

The CONTACT ID event codes received in the telephone format can be converted to the transmittable format, like the TCP/IP or UDP packages.

Operation

The communicator (stands as a simulated telephone line for the intruder alarm system) receives Contact ID event codes from the intruder alarm system and transmits it via GPRS network to the monitoring station and directs the coming back acknowledgments to the alarm system. Parallel with this function it is also able to transmit the contact events on its inputs to the monitoring station.

Main features

- Simulation of telephone line for intruder alarm system
- 2 contact inputs with independent signaling
- Capability of 2 independent monitoring receivers
- UDP or TCP/IP protocol transmission
- Configuration via USB using the PC software found in the communicator storage

Technical specification

- | | |
|-------------------------------|--------------------------------------|
| • Power supply | 5-32V (DC) |
| • Consumption | 300mA (max.) / 100mA (in idle state) |
| • Generated phone line values | |
| Line voltage | 48V |
| Loop current | 25mA |
| Load impedance | 100-470 Ohm |
| Dial tone | 425Hz |
| • Operating temperature | 0...+70°C |
| • Dimensions | 40x75mm |
| • GPRS mode | Quad Band (Class 12) |

Configuration

The communicator parameters can be configured by using the PC software available on the internal storage of the device. You can run the program directly from the unit's drive after connecting to USB.

1. Modem and GPRS

Settings of network connection

- a. **PIN code** Enter the PIN code
- b. **GPRS APN** Access Point Name provided by GSM operator
- c. **User** User name provided by GSM operator
- d. **Password** Password provided by GSM operator

2. INPUT1, INPUT2

Independent signalling contact inputs

- a. **Sensitivity** Minimum length of time of physical contact
- b. **Contact type** NC type input must be disconnected from the ground
NO type input must be shorted to ground
- c. **Event code** Optional CID event code
- d. **Reporting** Destination monitoring receivers in possible logical order
(only MS1, MS1 and MS2, MS1 or MS2, only MS2)













3. Monitoring station 1 és 2

- a. **IP address** IP address of monitoring receiver
- b. **Port** Dedicated port number for monitoring receiver
- c. **Protocol** UDP or TCP/IP
- d. **SIA prefix** Need if the alarm system object identifier is 4 character
- e. **Object identifier** Alarm system original object identifier
- f. **Replace obtained identifier** When receiving the CID format from the alarm system and before sending it to the monitoring receiver, is to replace the identifier in event code
- g. **Dialed number by alarm system** If the dialed number is same, or is not filled, the communicator sending the events to the monitoring receiver, otherwise don't.
- h. **Link test period** Periodic test data report to the monitoring receiver













LED indicators

The following LED indicators show the functional status of the communicator. In case of error RED TROUBLE LED is continuously ON, while GREEN LED is flashing according to the code of the error reason.

















NORMAL OPERATION

 AS comm	 AS comm	 AS comm
 MS comm	 MS comm	 MS comm
 GSM stat	 GSM stat	 GSM stat
 TROUBLE	 TROUBLE	 TROUBLE
Idle state	Reporting to monitoring receiver	Alarm system in communication

GSM NETWORK FAILURE

 AS comm	 AS comm	 AS comm
 MS comm	 MS comm	 MS comm
 GSM stat 3 flashing	 GSM stat 2 flashing	 GSM stat 1 flashing
 TROUBLE	 TROUBLE	 TROUBLE
SIM card missing or wrong	PIN missing or wrong	Poor GSM signal strength

GPRS network failure

 AS comm	 AS comm	 AS comm	 AS comm
 MS comm 4 fl.	 MS comm 3 fl.	 MS comm 2 fl.	 MS comm 1 fl.
 GSM stat	 GSM stat	 GSM stat	 GSM stat
 TROUBLE	 TROUBLE	 TROUBLE	 TROUBLE
APN missing	Wrong APN or GPRS network fault	Missing IP / Port or object ID	Wrong IP address